

HOW TO USE

Things you will need

- Glass (lukewarm water 180-200ml)
- Soft cloth



① Take off used Ink cartridge



② Fix a dropper to a nib.



③ Wash a nib in the lukewarm water.



④ Mix the lukewarm water and ink cleaner concentrate.



⑤ Soak a nib in the liquid for a whole day.



⑥ Rinse it with the clean water.



⑦ Fix an attached dropper to a nib again.
Please wash it 10 times in the clean water, therefore it works better.