


ORENZ is the mechanical pencil with an “Anti-Breaking lead system”. Thanks to the innovative system, your pencil lead will not break when writing.

How to use Orenz



- Click once to advance the pipe with the lead.
- Adjust length of the lead to the same length as the pipe. See Fig 1.
- Advancing too much may cause the lead to break during writing. See Fig 2.

How do you write without advancing the lead?



- Slide sleeve protects lead from breaking. see Fig 3.
- Slide features a smooth edge which will never tear paper when writing. See Fig 4.