

Cautions on Maintenance and Handling:

When you feel the need to clean your CYLINT Patina fountain pen, wipe gently with a damp cloth that has been wrung out well, then wipe again with a dry cloth, and always store in a dried state. Any residual moisture may cause the piece to corrode/become tarnished. Make sure not to get organic solvents such as alcohol or vinegar on the piece, as it may cause tarnishing. Any surface scratches caused by friction, etc. may lead to oxidation, promoting patina growth, corrosion or tarnishing. It is the nature of brass to change color over time and this change is a trait to be cherished. Therefore, returns/exchanges are not accepted for reasons such as patina growth, corrosion or tarnishing.

